

DEBO 7 ランナー250アドバンス初期設定

SYSTEM(システムメニュー)	DISPL(ディスプレイ)	4/10	
	BUZZE(ブザー設定)	STATE	ON
		THST k	INH
		TONE	5/10
	STMOD(スティックモード)	MODE 2	
	CALIB(キャリブレーション)		
	ABOUT(バージョン情報)	SOFT	VO.SB
MODEL(モデルメニュー)	SELEC(モデル選択)	RUNER	
	NAME(モデルネーム)	RUNER	
	COPY(コピー)		
	TRANS(モデル無線コピー)	RUNER	RUN NO
	RECEL(リシユル)	RUN NO	
	RESET(リセット)		
	TYPE(タイプ)	AERO	
	STEP(ステップ)	ELEV	4/20
		AILE	4/20
		THRO	4/20
		RODD	4/20
		ELEV	NORM
		AILE	NORM
		RUDD	NORM
	INPUT(デバイス選択)	FM SW	INH
		HLDSM	HOL D
	OUTPU(デバイスアウトプット)	GEAR	MIX
		GEAR	ACT
		FLAP	FMD
		FLAP	ACT
		AUX2	GEAR
		AUX2	ACT
	WING(スワッシュタイプ)	WING	NORM
		VTAIL	INH
	AMPLI(アンプ)	10	
		5	
		0	
		-5	
	FIXID(固定ID)	FIXID	OFF

FUNCTION(機能メニュー)	REVSW(リバー 스위ッチ)	REVSW	NORM	
		AILE	NORM	
		THRO	NORM	
		RUDD	NORM	
		GEAR	NORM	
		FLAP	NORM	
		AUX2	NORM	
	TRVAD(トラベル調整)	ELEV	U 100.0%	
			D 100.0%	
		AILE	L 100.0%	
			R 100.0%	
		THRO	H 100.0%	
			L 100.0%	
		RUDD	L 100.0%	
			R 100.0%	
		GEAR	100.0%	
			-100.0%	
		FLAP	U 100.0%	
			D 100.0%	
		AUX2	100.0%	
			-100.0%	
	SUBTR(サブトリム)	ELEV	0.00%	
		AILE	0.00%	
		THRO	0.00%	
		RUDD	0.00%	
		GEAR	0.00%	
		FLAP	0.00%	
		AUX2	0.00%	
	DREXP(デュアルレートとエキスポネンシャル)	CHANN	ELEV	
		POSIT	POS 0	
		D/R	100%	
		EXP	LINE	
	THHLD(スロットルホールド)	STATE	INH	POS 0
	THCRV(スロットルカーブ)	SRVHD	YES	
	GYRO(ジャイロ設定)	SWITC	MIX	
			POS 0	50.0
			POS 1	50.0

			POS 2	50.0
	AI-RU(ガバナー)	POSOL	0%	
		POSOR	0%	
		POSIL	0%	
		POSIR	0%	
		THST k	INH	
		SWITC	POS 0	
	EL-FL(スワッシュミックス)	POSOU	0%	
		POSOD	0%	
		POSIU	0%	
		POSID	0%	
		THST k	INH	INH
		SWITC	POS 0	INH
			AND	INH
			FMD 0	INH
			FMD 1	INH
			FMD 2	INH
			FPNRM	INH
			FPMID	INH
			FPLND	INH
			D/R	INH
			HOLD	
			GEAR	
	RU-AE(ピッチカーブ)	ELPOL	0%	
		ELPOR	0%	
		ELPIL	0%	
		ELPIR	0%	
		AIPOL	0%	
		AIPOR	0%	
		AIPIL	0%	
		AIPIR	0%	INH
		THST k	INH	INH
		SWITC	POS 0	
			AND	INH
			FMD 0	INH
			FMD 1	INH
			FMD 2	INH

			FPNRM	INH
			FPMID	INH
			FPLND	INH
			D/R	INH
			HOLD	INH
			GEAR	INH
	PRGMX(プログラムミックス)	PROG 1	INH	
		PROG 2	INH	
		PROG 3	INH	
		PROG 4	INH	
		PROG 5	INH	
		PROG 6	INH	
		PROG 7	INH	
		PROG 8	INH	
	MONIT(モニター)	ELEV	0%	
		AILE	0%	
		THRO	-100%	
		RUDD	0%	
		GEAR	-100%	
		FLAP	+100%	
		GYRO	0%	
		FMD	POS 0	
		MIX	POS 0	
		D/R	POS 0	
		HOLD	POS 0	
		GEAR	POS 0	
		TRN	POS 0	
	SAFE(フェイルセーフ)	ELEV	HOLD	
		AILE	HOLD	
		THRO	HOLD	
		RUDD	HOLD	
		GEAR	HOLD	
		FLAP	HOLD	
		GYRO	HOLD	
	TRAIN(トレーニング)	ELEV	INH	
		AILE	INH	
		THRO	INH	

		RUDD	INH
		GEAR	INH
		FLAP	INH
		AUX2	INH
	TIMER(タイマー)	TYPE	STOPW